


► COMMON SHEET\_PRINT

NO	PART NO	ITEM	QTY
1	ATTO0ACP001	BACKBOARD COVER PET	1
2	ATTO0ACP002	BILLBOARD FND COVER ACR	1
3	ATTO0ACP003	BILLBOARD PC	1
4	ATTO0ACP004	FRONT CASE BUTTON COVER ACR	1
5	ATTO0ACP005	FRONT MAIN FRAME L ACR	1
6	ATTO0ACP006	FRONT MAIN FRAME R ACR	1
7	ATTO0ACP016	PLAYER TURN LED COVER ACR	1
8	ATTO0ACP008	SPEAKER COVER ACR L	1
9	ATTO0ACP009	SPEAKER COVER ACR R	1
10	ATTO0ACP010	TARGET MAIN FRAME L ACR	1
11	ATTO0ACP011	TARGET MAIN FRAME R ACR	1
12	ATTO0ACP014	FRONT MAIN FRANE LINEAR L ACR	1
13	ATTO0ACP015	FRONT MAIN FRANE LINEAR R ACR	1



► COMMON SHEET

A1	MTTO0SHE001	BILLBOARD DECO TITLE	1
A2	MTTO0SHE002	TARGET SHEET A-1	1
A3	MTTO0SHE003	TARGET SHEET A-2	1
A4	MTTO0SHE004	TARGET SHEET B-1	1
A5	MTTO0SHE005	TARGET SHEET C-1	1
A6	MTTO0SHE006	TARGET SHEET B_C-2	1
A7	MTTO0SHE007	BALL BLOCK DECO SHEET	1
A8	MTTO0SHE008	PLAY GROUND TITLE SHEET	1
A9	MTTO0SHE009	HOW TO PLAY SHEET	1
A10	MTTO0SHE010	FRONT SHEET	1
A11	MTTO0SHE011	FRONT DOOR SHEET L	1
A12	MTTO0SHE012	FRONT DOOR SHEET R	1
A13	MTTO0SHE013	COIN COVER SHEET 1P	1
A14	MTTO0SHE014	BILL COVER SHEET 1P	1
A15	MTTO0SHE015	COIN COVER SHEET 2P	1
A16	MTTO0SHE016	BILL COVER SHEET 2P	1
A17	MTTO0SHE032	SIDE GUARD DECO SHEET L	1
A18	MTTO0SHE033	SIDE GUARD DECO SHEET R	1
A19	MTTO0SHE019	TARGET SIDE SHEET L	1
A20	MTTO0SHE020	TARGET SIDE SHEET R	1
A21	MTTO0SHE025	BUTTON SHEET 1P	1
A22	MTTO0SHE026	BUTTON SHEET 2P	1
A23	MTTO0SHE034	TARGET SENSOR SHEET A	1
A24	MTTO0SHE035	TARGET SENSOR SHEET B	1
A25	MTTO0SHE036	TARGET SENSOR SHEET C	1

