

UNPACKING LIST

* Please make sure to remove all items below before turning on product.

1



– Tilt Alarm : Using Nipper (or similar tools), please cut off the tie around Tilt Alarm

2



– Game panel acryl cover sheet

3



– Prize acryl cover sheet (16Ea)