

* INSTALL INFORMATION

1) INSTALLATION SPACE


- ※ Maintenance zone & Play zone distance maintenance
: should have at least 1800 mm * 2400mm each

2) MAINTAIN PRODUCT FLATNESS

- ※ After installation is complete
: adjust the 4 adjuster so that the product is stably leveled.


3) IMPORTANCE

- ※ This product should be indoor use and out of direct sunlight.



* UNPACKING


1) PACKING LOCATION



▼ 1
COMPONENTS

2) COMPONENTS

no	PART NAME	Q'TY	SPARE	no	PART NAME	Q'TY	SPARE
1	AC CORD	1		5	SCREW TH_BL 4x10	28	4
2	MANUAL	1		6	SCREW TH_BL 4x16	14	4
3	WRENCH 2.5, 3, 4, 5 mm	EACH 1					
4	SCREW TH_NI 4x8	3	2				



* INSTALL(REEL TO PAGE 5 OF THE MANUAL)